

## Leaving the Building

If you are leaving the building, go to Keypad and key in your PIN code, or present your Tag.

Exit tone Starts

The appropriate area (ABCD) keys will illuminate.

(If flexi-set is enabled you will be able to choose which areas you set, see page D2)

## Leave by agreed Exit Route

### Close and Lock the Final Exit Door

Finally, press the 'Push to Set' button (if fitted) that is mounted externally by the final exit door.

Exit tone will cease

**Euro-MERiDIAN is now SET**



Exit Timer



If your exit is timed, you will see the above screen.

If you use a Push-to-Set button, or final-door-set, you will see the screen below.

Leave vi a  
Exi t Route