



## Setup Users (Cont.)

To setup users proceed as follows:

1. Ensure that "User menu 2" is selected. Press **[4]** to select the Setup users option. The display will show:



2. Enter the user number (02-31) that is required to be setup, e.g., to setup user 12 enter "12" followed by **[ENT]**. The display will show the current user type (Note: If the code is currently unassigned, the display will show "Not in use":



3. Select a new user type by pressing:

- |                           |                               |
|---------------------------|-------------------------------|
| <b>[1]</b> for Master     | <b>[7]</b> for PA Code        |
| <b>[2]</b> for Standard   | <b>[8]</b> for Access         |
| <b>[3]</b> for Holiday    | <b>[9]</b> for Full set group |
| <b>[4]</b> for Set Only   | <b>[A]</b> for Code set grp A |
| <b>[5]</b> for Reset Only | <b>[B]</b> for Code set grp B |
| <b>[6]</b> for Duress     | <b>[C]</b> for Code set grp C |


e.g., to select user type "Standard" press "2". The display will show:



4. When the display shows the required user type press **[ENT]** to accept. The display will show:




5. Enter a 4 digit passcode for the selected user, e.g., enter "2580". The display will show:



6. Press **[ENT]** to update with new passcode, a multi-tone will indicate that the passcode has been accepted and the display will return to step 1. A low tone indicates that the passcode is not available. Re-enter, trying a different 4 digit passcode.

7. Repeat from step 1 for other users or press **[ESC]** to return to "User menu 2".

 To delete user passcodes 02-31 from the system, select the user number you wish to delete at step 2, then enter your own passcode at step 5.