

Quick Reference Guide

| | | |
|-----------------|---|----------------------------------|
| Full Set | Enter your passcode | X X X X |
| Part Set | Enter your passcode | X X X X |
| | Press A, B or C as required | A or B or C |
| Unset | Enter your passcode | X X X X |
| Silent Full Set | Enter your passcode | X X X X |
| | Press 8 | 8 |
| Silent Part Set | Enter your passcode | X X X X |
| | Press A, B or C as required | A or B or C |
| | Press 8 | 8 |
| Bell Test | Enter your passcode | X X X X |
| | Press [ENT] within 5 secs. | ENT |
| | Press 1 (sounders on) | 1 |
| | Press [ESC] when finished | ESC |
| Walk Test | Enter your passcode | X X X X |
| | Press [ENT] within 5 secs. | ENT |
| | Press 2 | 2 |
| | Conduct Walk Test | Conduct Walk Test |
| | Press [ESC] when finished | ESC |
| Remote Reset | Enter your passcode | X X X X |
| | Press [ENT] within 5 secs. | ENT |
| | Press 3 | 3 |
| | Contact your central station and quote 4 digit number | |
| | Enter reply number | X X X X |
| | Press [ENT] | ENT |
| Change Passcode | Enter your passcode | X X X X |
| | Press [ENT] within 5 secs. | ENT |
| | Press 4 | 4 |
| | Enter new passcode | X X X X |
| | Press [ENT] to accept | ENT |
| | Press [ESC] when finished | ESC |